



EN

AIR PURIFIER

Pury Pury colour



OPERATING INSTRUCTIONS

Read the instructions carefully before operating or servicing the air purifier.

Observe all the safety instructions; failure to observe the instructions may lead to accidents and/or damage. Store these instructions in a safe place for future reference.

GENERAL OPERATING AND SAFETY INSTRUCTIONS

- **This appliance is a highly efficient air purifier designed for domestic use only!**
- Use this air purifier only as outlined in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or malfunctions.
- The unit must be placed in a vertical position at all times.
- Ensure that the available power source conforms to the required voltage and frequency (220 - 240V/50Hz).
- This appliance can be used by children aged from 8 years and above and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Make sure that the plug is fully inserted. Do not use multiple adapters. Do not touch the plug with wet hands. Make sure that the plug is clean.
- This product is not a toy. Children should be adequately supervised to ensure that they do not play with the appliance.
- **Disconnect the main power when the appliance is not in use or during cleaning operations. Keeping the appliance plugged in may cause electric shocks or accidents.**
- To disconnect the appliance, set the switch to OFF and remove the plug from the socket. Pull on the plug only. Do not pull the cord.
- Do not bend, drag or twist the cord, or apply force to remove it. **Do not operate the unit if its cable or plug are damaged; doing so can cause fires or electric shock.** If the power cord is damaged, it must be replaced by a service centre.

- **Do not place heavy objects on the appliance.**
- **Do not use the appliance on unstable or sloping surfaces.**
- The air purifier must be placed **at least 50 cm** from the wall or from other obstacles, to ensure proper heat dissipation.
- **Close all open windows to maximise air purification efficiency.**
- **Do not insert objects or sharp instruments into the air outlet grille.**
- **Do not cover the air intake and outlet grilles in any way.**


WARNING!

In the event of an anomaly, switch the appliance off and unplug it immediately. Do not dismantle, repair or modify this product freely. In the event of a malfunction, contact the after-sales service centre directly.

- Do not immerse the power cord, plug or any other part of the appliance in water or other liquids.
- Do not expose the air purifier to direct sunlight.
- Keep the appliance well away from sources of heat which could cause plastic parts to become warped.
- Do not spray insecticides, oils or paints near the appliance; doing so may damage its plastic parts or start a fire.
- **Keep flammable gases and oils away from the appliance!**
- **Do not move the appliance while it is operating, as this may cause malfunctions.**


DESCRIPTION OF PARTS

FRONT VIEW



- 1) CONTROL PANEL
- 2) AIR OUTLET
- 3) PLUG

REAR VIEW



- 4) HANDLE
- 5) AIR INLET

PRE-FILTER. Its main function is to filter the coarsest particles, which consequently allows for extending the life of the HEPA filter.

ACTIVATED CARBON FILTER: absorb smell.

HEPA FILTER. It can filter particles with a diameter above 0.3 microns and effectively eliminates pollen, smoke, animal hairs, mould and dust.

IONISER. Generates a large amount of negative ions. Household air is filled with positive ions generated by many appliances such as television sets and radios. Using the ANION mode helps to release plenty of negative ions which naturally abound in areas renowned for their high well-being, such as mountainous areas. The air becomes fresh and crisp, just like mountain air.

CONTROL PANEL



POWER

Connect unit to supply: you can hear a beep and all the LEDs flash. The LED on AQI button flashes for 3" taking various colors: blue, orange and red.

After two minutes the sensor is ready to work: all the LEDs turn off except the POWER one and the unit is on standby.

ON/OFF BUTTON

Press this button to turn on the unit in AUTO mode. The sensor needs two minutes to be able to work consistently: during this time the fan speed is set on medium speed (orange LED). Then the unit automatically adjusts the fan speed according to air quality and the LED AQI will assume the corresponding color.

COLOURING ACCORDING TO THE AIR QUALITY IN AUTO MODE

Air quality	Good	Medium	Bad
LED colour	Blue	Orange	Red
Fan speed	Low	Medium	High

Press this button again to turn off the unit (stand by) and all the LEDs turn off.

TIMER BUTTON

Press this button to set the timer from 1h to 8h.

SPEED BUTTON

Press this button to adjust the fan speed according to the following sequence: AUTO – LOW – MID – HIGH.

AUTO:

In AUTO mode, the fan speed is set initially on medium speed (orange LED). After 120 ", the unit automatically adjusts the fan speed according to air quality and the LED AQI will assume the corresponding color.

SLEEP BUTTON

1. Press this button for the appliance to operate more silently. The fan speed will be set to the minimum speed.
2. When the light of this button blinks the carbon filter and the HEPA filter may need to be replaced. Press the sleep button for seconds after changing the filters and the light stops blinking.


ANION BUTTON

Press this button to turn on or turn off the emission of negative ions.


CLEANING AND REPLACEMENT OF THE FILTERS

Pre-filter	Clean it every one month
Composite filter	Replace it every 3-6 months

Filter life will be vary by usage and environment.



Press the lever down and pull the rear panel towards you.



After removing the rear panel, remove the filter unit in the following order: back over and composite filter.

Cleaning the pre-filter

For improved efficiency, the pre-filter should be cleaned regularly. First use a vacuum cleaner then water to wash the pre-filter. Use neutral detergent if the pre-filter is very dirty.

Put the filter back into place after cleaning it and leaving it to dry.

CLEANING AND MAINTENANCE

⚠ Warning

Always pull the air purifier's plug out of the power socket before cleaning it, to prevent electric shocks or malfunctions.

⚠ Warning

Do not wet or immerse the air purifier in water, as this may cause electric shocks.

Use a damp and soft cloth to clean the outer surface of the air purifier.

Do not use solvents, petrol, xylene, talcum powder or brushes to clean the unit: these may damage the surface or colour of the casing.

Cleaning the casing

Use a damp and soft cloth to clean the outer surface of the appliance.

Do not use excessively hot water, solvents, petrol or other aggressive chemical compounds, talcum powder or brushes: these may damage the surface or colour of the casing.

Remove stains using lukewarm water with a little neutral detergent.

Do not pour water onto the air purifier to clean it, as this may damage the internal components or cause a short circuit.



INFORMATION ON CORRECT DISPOSAL OF THE PRODUCT ACCORDING TO EUROPEAN DIRECTIVE 2012/19/EU ON THE DISPOSAL OF ELECTRICAL AND ELECTRONIC WASTE MATERIALS'

This appliance must not be scrapped with domestic waste at the end of its life cycle. We call your attention to the crucial role played by the consumer in the reuse, recycling and other forms of recovery of such waste.

The dismantled appliance, with its components collected separately, must be delivered to the local waste disposal facility or returned to the dealer free of charge when purchasing a new equivalent appliance.

Sorted disposal of electric and electronic equipment prevents potentially negative consequences on the environment and human health due to improper scrapping, and also allows the constituent materials to be recovered and recycled, with significant savings in terms of energy and resources.

The sorted disposal requirement is indicated by the crossed dustbin symbol affixed to the product.



improve your life

www.argoclima.com